

Pure Freude
an Wasser

GROHE
WAVES

new

PRECISE
CONTROL
**AT YOUR
FINGERTIPS**

GROHE SMARTCONTROL®
KITCHEN FAUCETS



GROHE
WAVES



31 616 DC0
Essence SmartControl
pull-out faucet

GROHE SMARTCONTROL® **DESIGNED TO MAKE A DIFFERENCE**

How can we make everyday kitchen tasks effortless in a fresh, new way? This intriguing question resulted in the creation of the GROHE SmartControl® faucet. Distinctly different in design and function, with no lever to regulate or handles to fine-tune, it's sleeker and more streamlined than most. Equipped with the exclusive GROHE SmartControl® button at the tip of the spout, it enables easy push-button on/off and hands-free convenience, essential features in today's busy kitchen.

Available in two impressive styles:

GROHE Zedra

Clean and contemporary, the perfectly tapered base of the GROHE Zedra creates an impressive focal point.

Essence

Defined by a gently curved, cylinder base, Essence makes an impression in every kitchen, from traditional to modern.

PRACTICAL PERFECTION

Uniquely designed to make everyday tasks effortless, the exclusive GROHE SmartControl® button is conveniently located at the tip of the spout. Simply push the button to start water flow, push again to shut water off, ideal when hands are sticky or occupied. Turn the SmartControl button to adjust water volume from a soft stream to a powerful flow, perfect for rinsing vegetables or quickly filling pots. A gentle turn of the valve at the base of the faucet delivers the perfect water temperature.

The GROHE SmartControl kitchen faucets are precision engineered, incorporating time-tested GROHE features for lasting beauty and superior performance.

Sleek Design – No lever or handles to obstruct the clean lines of each style

Push-Button Convenience – SmartControl button for on/off ease and hands-free capability

Temperature Adjustment – Regulate water temperature by turning dial at base of faucet

Pull-Out Spray Head – Allows for optimal reach within the sink

Swivel Spout – Increases flexibility and convenience



Push button to start & stop the water flow



Turn button to set the water volume from soft stream to powerful flow



Turn dial at base to the left or right to adjust water temperature



LEAD AND NICKEL FREE

Isolated inner waterways protect water from contact with lead and nickel.



GROHE SMARTCONTROL®

Push to start and stop water flow. Turn to adjust water volume.



SWIVELSTOP

Limited 140° swivel prevents flooding.

TEMPERATURE ADJUSTMENT

Turn gently left or right to regulate water temperature.



GROHE QUICKFIX® PLUS

Requires minimal threading for faster installation.

31 559 002
GROHE Zedra SmartControl pull-out faucet



31 559 DC2
GROHE Zedra SmartControl
pull-out faucet



ESSENCE SMARTCONTROL & GROHE ZEDRA SMARTCONTROL



● ●
31 616 000/DC0
Essence SmartControl
pull-out faucet



● ●
31 559 002/DC2
GROHE Zedra SmartControl
pull-out faucet



Colour options:

● 00 | StarLight® Chrome


● DC | SuperSteel

Follow us



DISCOVER THE WORLD OF GROHE AT WWW.GROHE.CA

QUALITY




From the first design sketch to the final product to after-sales services: Our customers can rely on our engineered in Germany sense of perfectionism.

TECHNOLOGY



We constantly drive innovation to enrich your everyday water experience, delivering smart solutions on the path of the digitization of water.

DESIGN



Our highly awarded design DNA's recipe for success is simple: Merging the contemporary and the timeless into products that feel like they were designed just for you.

SUSTAINABILITY



Water is our passion. We care about every drop and our CSR commitment goes even beyond one element alone: We strive to protect all of our planet's resources for future generations.

GROHE America
160 Fifth Avenue, 4th Floor
New York, NY 10010
Tel.: 1-800-444-7643
www.grohe.us

LIXIL Canada Inc.
5900 Avebury Road
Mississauga, Ontario, L5R 3M3
Tel.: 1-888-644-7643
info@grohe.ca
www.grohe.ca

© 09/2021 LIXIL Canada Inc.

PART OF **LIXIL**